

# Quality Enclosures

## FRAMED DOOR & PANEL

SUPERIOR TUB ENCLOSURES  
CUSTOM SHOWER DOORS

101-H WINDSOR PL, CENTRAL ISLIP, NY 11722  
2025-E PORTER LAKE DR, SARASOTA, FL 34240  
3348-B103 TRICKUM RD, WOODSTOCK, GA 30188

## INSTALLATION INSTRUCTIONS

**Tools Needed:** Tape measure, hacksaw, level, power drill, 3/16 carbide masonry drill bit, 7/64 drill bit, phillips screw tip, and silicone caulk.

- Step 1:** Measure the distance between the walls at the base of the shower and cut the bottom track 1/16" less than opening. Position the track at the base and mark the installation holes with a felt tip marker. Drill holes using 3/16 masonry bit and insert screw anchors. Secure track with #8 x 1" installation screws.
- Step 2:** Plumb the u-channels along the walls with a level (medium u sits on top of track and small u sits inside bottom track) and mark the installation holes with a felt tip marker. Drill holes using 3/16 masonry bit and insert screw anchors. Secure u-channels with #8 x 1" installation screws.
- Step 3:** Slide panel inside medium u-channel. Slide striker (or hinge jamb of door) over panel and hinge jamb of door (or striker) over small u-channel. The panel sits inside bottom track - hinge jamb and striker sits on top of track.
- Step 4:** Adjust hinge jamb, striker, and panel to desired position. Drill holes along medium u-channel through panel, along striker (or hinge jamb) through panel, and along hinge jamb (or striker) through small u-channel. Secure with #6 x 3/8" screws.
- Step 5:** Measure distance from wall to wall across top of u-channels. Cut header 1/16" less than this dimension and slip over u-channels. Drill holes at ends of header through u-channels and secure with #6 x 3/8" screws.
- Step 6:** Measure opening between hinge jamb and striker. Cut threshold insert to this dimension and slide the insert inside bottom track below the door.
- Step 7:** Place drip cap w/ vinyl along bottom of door between hinge jamb and striker. Drill at holes on drip cap through bottom of door and secure with #6 x 3/8" screws.
- Step 8:** Install male and female pulls through pre-drilled holes in door using #8-32 x 5/8" screws.
- Step 9:** Caulk the inside of the u-channels and track where the edge meets the wall and base. Outside caulking is optional.

