

Quality Enclosures

SEMI-FRAMELESS SHOWER DOOR without HEADER

SUPERIOR TUB ENCLOSURES
CUSTOM SHOWER DOORS

101-H WINDSOR PL, CENTRAL ISLIP, NY 11722
2025-E PORTER LAKE DR, SARASOTA, FL 34240
3348-B103 TRICKUM RD, WOODSTOCK, GA 30188

INSTALLATION INSTRUCTIONS

Tools Needed: Tape measure, hacksaw, level, power drill, 3/16 carbide masonry drill bit, 7/64 drill bit, phillips screw tip, rubber mallet, and silicone caulk.

Step 1: Measure the distance between the walls at the base and cut the bottom track at 1/16" less than the opening.

Step 2: Place bottom track on base and set u-channels inside the track along walls at the center line. Plumb u-channels with a level and mark installation holes with a felt tip marker. Drill holes using 3/16 masonry bit and insert screw anchors. Secure u-channels with #8 x 1" installation screws.

Step 3: Center handle along edge of door, with rubber strip wedged in between, and knock it all the way onto glass using rubber mallet.

Step 4: Center one-piece magnet along striker and cut striker seals at both ends.

Step 5: Slide hinge jamb of door and striker over u-channels.

Step 6: Adjust hinge jamb and striker to desired position. The unit should be flush across the top. Drill holes along hinge jamb through u-channel and along striker through u-channel. Secure with #6 x 3/8" screws.

Step 7: Measure opening between hinge jamb and striker. Cut threshold insert to this dimension and snap into bottom track.

Step 8: Measure from edge of glass door to hinge jamb and cut drip cap at 1/8" less than this dimension. Trim 1-1/4" off top portion (flap and legs) of drip cap on hinge side. Trim 3/8" off flap and inside leg of drip cap on strike side to ensure that door will close properly. Slide drip cap onto bottom of door.

Step 9: Caulk the inside of the u-channels and bottom track where the edge meets the walls and base. Outside caulking is optional.

