

# Quality Enclosures

## FRAMED SHOWER DOOR without HEADER

SUPERIOR TUB ENCLOSURES  
CUSTOM SHOWER DOORS

101-H WINDSOR PL, CENTRAL ISLIP, NY 11722  
2025-E PORTER LAKE DR, SARASOTA, FL 34240  
3348-B103 TRICKUM RD, WOODSTOCK, GA 30188

## INSTALLATION INSTRUCTIONS

**Tools Needed:** Tape measure, hacksaw, level, power drill, 3/16 carbide masonry drill bit, 7/64 drill bit, phillips screw tip, and silicone caulk.

**Step 1:** Mark the center line of the base along the walls. Plumb the u-channels along the walls with a level and mark the installation holes with a felt tip marker. Drill holes using 3/16 masonry bit and insert screw anchors. Secure u-channels with #8 x 1" installation screws.

**Step 2:** Slide hinge jamb of door and striker over u-channels.

**Step 3:** Adjust hinge jamb and striker to desired position. The unit should be flush across the top. Drill holes along hinge jamb through u-channel and along striker through u-channel. Secure with #6 x 3/8" screws.

**Step 4:** Measure opening between hinge jamb and striker. Cut L-angle dam strip to this dimension and affix onto base using double sided tape.

**Step 5:** Place drip cap w/ vinyl along bottom of door between hinge jamb and striker. Drill at holes on drip cap through bottom of door and secure with #6 x 3/8" screws.

**Step 6:** Install male and female pulls through pre-drilled holes in door using #8-32 x 5/8" screws.

**Step 7:** Caulk the inside of the u-channels and track where the edge meets the wall and base. Outside caulking is optional.

