



Tools Needed: Tape measure, hacksaw, level, power drill, 3/16 masonry drill bit, 7/64 drill bit, phillips screw tip, and silicone caulk.

Step 1: Mark the center lines on the base. Position the center track (the one mitred on both ends) at the center line in the middle of the base and mark the installation holes with a felt tip marker. Drill holes using 3/16 masonry bit and insert screw anchors. Secure track with #8 x 1" installation screws.

Step 2: Measure the distance from the end of the center track to the left wall and cut the left track to this dimension. Position the left track at the center line on the left side of the base and mark the installation holes. Drill holes and insert screw anchors. Secure track with installation screws. Do the same for the right track.

Step 3: Set u-channels on top of tracks and plumb along the walls with a level and mark the installation holes. Drill holes and insert screw anchors. Secure u-channels with #8 x 1" installation screws.

Step 4: Slide panels into u-channels. Slide corner posts (notched part goes into bottom track) over panels. Adjust panels and plumb corner posts. Drill holes along u-channels and corner posts through panels and secure with #6 x 3/8" screws.

Step 5: Slide hinge jamb of door over one corner post and striker over other corner post. Adjust hinge jamb and striker. Drill holes along both through corner posts and secure with screws.

Step 6: Measure distance from left corner post to wall across the top and cut left part of assembled header 1/8" more than this dimension. Do the same for the right part of the header.

Step 7: Slip header over corner posts and u-channels. Drill holes on header through corner posts and u-channels. Secure with #6 x 3/8" screws.

Step 8: Measure opening between hinge jamb and striker. Cut threshold insert to this dimension and slide the insert inside bottom track below the door.

Step 9: Place drip cap w/ vinyl along bottom of door on the inside between hinge jamb and striker. Drill at holes on drip cap through bottom of door and secure with #6 x 3/8" screws.

Step 10: Install male and female pulls through pre-drilled holes in door using #8-32 x 5/8" screws.

Step 11: Caulk inside (outside is optional) of u-channels and track where edge meets walls and base.

