

**Tools Needed:** Tape measure, hacksaw, level, power drill, 3/16 carbide masonry bit, 7/64 bit, phillips screw tip, rubber mallet, and silicone caulk.

**Step 1:** Measure the distance between the walls at the base and cut the bottom track at 1/16" less than the opening.

**Step 2:** Place bottom track on base and set u-channels inside the track along walls on center line. Plumb u-channels with a level and mark installation holes with a felt tip marker. Drill holes using 3/16 masonry bit and insert screw anchors. Secure u-channels with #8 x 1" installation screws.

**Step 3:** Place two setting blocks inside the track and set panel on the blocks. Slide panel into u-channel and secure with thin vinyl on both sides. Set inline post inside the track and slide over panel. Again, secure with thin vinyl on both sides.

**Step 4:** Center handle along edge of door, with rubber strip wedged in between, and knock it all the way onto glass using rubber mallet.

**Step 5:** Center one-piece magnet along striker and cut striker seals at both ends.

**Step 6:** Slide hinge jamb of door (or striker) over u-channel and striker (or hinge jamb of door) over inline post.

**Step 7:** Adjust hinge jamb and striker to desired position. If necessary, adjust panel as well. Drill holes along hinge jamb of door (or striker) through u-channel and along striker (or hinge jamb of door) through inline post. Secure with #6 x 3/8" screws.

**Step 8:** Measure distance from wall to wall across top of u-channels. Cut header 1/16" less than this dimension and slip over u-channels. Drill holes at header through u-channels and post. Secure with #6 x 5/8" screws.

**Step 9:** Push thick vinyl into header and bottom track at the panel on both sides.

**Step 10:** Measure opening between hinge jamb and striker. Cut threshold inserts to this dimension and snap into header and bottom track.

**Step 11:** Measure from edge of glass door to hinge jamb and cut drip cap at 1/8" less than this dimension. Trim 1-1/4" off top portion (flap and legs) of drip cap on hinge side. Trim 3/8" off flap and inside leg of drip cap on strike side to ensure that door will close properly. Slide drip cap onto bottom of door.

**Step 12:** Caulk the inside of the u-channels and bottom track where the edge meets the walls and base. Outside caulking is optional.

