

Tools Needed: Tape measure, hacksaw, level, power drill, 3/16 carbide masonry drill bit, 7/64 drill bit, phillips screw tip, and silicone caulk.

Step 1: Measure the distance between the walls at the bottom of the tub and cut the bottom track 1/2" less than opening.

Step 2: Insert the jambs over the ends of the track. Plumb the jambs with a level and mark the installation holes with a felt tip marker. Drill holes using 3/16 masonry bit and insert screw anchors. Secure jamb (and bumpers) with #8 x 1" installation screws (on fiberglass applications, it may be necessary to radius the bottom of the jambs).

Step 3: Position the sta-kleen guide at center of bottom track and drill through the track at holes in the guide. Secure guide with #6 x 3/8" screws.

Step 4: Measure the distance from wall to wall across the top of the jambs. Cut the header 1/16" less than this dimension. Slip the header over the jambs.

Step 5: The door next to the shower head is to be the inside door. To install the inside door, lift the door into the inside track of the header and lower it into the inside track of the sta-kleen guide. Install the outside door in the same manner using the outside track and guide. Secure the header from the inside of the tub with #6 x 3/8" screws. Secure where the header overlaps jambs. Adjust the rollers so that the doors meet evenly.

Step 6: Install towel bars directly to doors through pre-drilled holes in glass.

Step 7: Caulk the inside of the jambs and track where the edge meets the wall and tub. Outside caulking is optional.

