

Quality Enclosures

FRAMELESS DOOR & PANEL

SUPERIOR TUB ENCLOSURES
CUSTOM SHOWER DOORS

101-H WINDSOR PL, CENTRAL ISLIP, NY 11722
2025-E PORTER LAKE DR, SARASOTA, FL 34240
3348-B103 TRICKUM RD, WOODSTOCK, GA 30188

INSTALLATION INSTRUCTIONS

Tools Needed: Tape measure, shears, level, power drill, $\frac{3}{16}$ masonry drill bit, phillips screw tip, and silicone caulk.

Step 1: Place base channel on saddle at center line with mitred end against wall and mark installation holes with felt tip marker. Drill holes using $\frac{3}{16}$ bit and insert screw anchors. Secure channel with #8 x $1\frac{1}{2}$ " screws and apply caulking at the screws.

Step 2: Align wall channel and base channel at mitred ends. Plumb along wall with level and mark installation holes with felt tip marker. Drill holes using $\frac{3}{16}$ bit and insert screw anchors. Secure channel with #8 x $1\frac{1}{2}$ " screws and apply caulking inside both channels at the mitred ends.

Step 3: Place two setting blocks inside base channel and set panel on blocks. Slide panel into wall channel until side edge is flush with end of base channel. Top edge should also be flush with end of wall channel while making sure side edge remains plumb. Adjustments can be made by using extra setting blocks and/or shims.

Step 4: Cut polycarbonate strike jamb to panel height. Trim $\frac{3}{4}$ " off legs of strike jamb at end towards bottom of panel and slip onto side of panel.

Step 5: Remove screws and inside plates of hinges. Place hinges in notches on door and replace inside plates and screws. Make sure gaskets are between door and hinges.

Step 6: Place $\frac{3}{8}$ " - $\frac{1}{2}$ " blocks on base and set door on blocks with the hinges against the wall (top of door should be flush with top of panel). Position door along center line against strike jamb and mark installation holes with felt tip marker.

Step 7: Remove door and hinges from door. Drill holes using $\frac{3}{16}$ bit and insert screw anchors. Secure hinges with #10 x 2" screws.

Step 8: Set door on hinges as before. Adjust door by loosening and re-tightening screws on inside plate. Make sure gap between door and strike jamb is even.

Step 9: Disassemble handle and install through holes on door. Make sure grommets are in holes and plastic washers are between door and metal washers.

Step 10: Cut polycarbonate drip cap to width of door. Trim $\frac{3}{8}$ " off flap and inside leg of drip cap on strike side and slide drip cap onto bottom of door.

Step 11: Measure from top of door to top of upper hinge and cut polycarbonate "h" seal to this length. Slip onto door with the soft flap to the inside of the shower. Measure from bottom of upper hinge to top of lower hinge and cut another "h" seal to this length. Slip onto door. Measure from bottom of lower hinge to floor and cut another "h" seal $\frac{1}{16}$ " less than this length. Trim 1" off legs of "h" seal at end towards bottom of door and slip onto door.

Step 12: Caulk inside of channels where the edges meet the wall and base and where the edges meet the glass. Outside caulking is optional.

